

www.perthconcreteresurfacing.com.au

sales@perthconcreteresurfacing.com.au

0418 837 699

# **How to Maintain Your Concrete Resurfacing**

Here are some tips for preserving the life and appearance of your Resurfacing:

## Sweep it up

When cleaning a standard resurfaced floor, it's recommended that you first sweep up all the dust and debris.

## Hose it down

Once debris has been cleared, a good hose down with a high-pressure water hose should do the trick. Use a sideways motion working from the rear to the front of the area. Pay particular attention to any cracks or crevasses that may have collected extra dirt.

## Scrub for good measure

For extra cleaning, use a concrete specific cleaner and scrub into the surface with a brush or broom. Rinse again at high pressure.

A regular clean is recommended to keep your exterior floors clean and tidy. Just because your floors are made from concrete, it doesn't mean they don't need a little TLC every now and then.

## Clean and Re-apply Sealer as Needed!

How often this is required will depend on exposure to weather conditions and the amount of traffic it receives. Generally, you should re-seal concrete resurfacing every three to five years or when the finish begins to show wear.

#### **Remove Stains Immediately!**

While a sealer will help protect resurfacing from stain absorption it is still a very good idea to remove oil, grease and other spills from your resurfacing as soon as possible.

If your resurfacing does look like it requires some maintenance and cleaning, we can either provide you with advice on cleaning, we also have specific Resurfacing cleaner, or we can provide you with cleaning and pressure washing services.